

Contents

1	Overview	1–1
1.1	Introduction	1–2
1.1.1	Additional Information	1–3
1.2	Product Description	1–4
1.2.1	Exchange Units and Remote Units	1–4
1.2.2	Transmission	1–5
1.2.3	RIM and C–RIM Architectures	1–5
1.2.4	Panel Types	1–5
1.2.5	OA&M	1–7
1.2.6	COMNET–2 Network Management	1–8
1.3	Services	1–10
1.4	Support	1–12
1.4.1	Help Desk	1–12
1.4.2	Spares	1–12
1.4.3	Repairs	1–12
2	System Application	2–1
2.1	Introduction	2–2
2.2	Main Cable Relief Using Optical Fibre	2–3
2.3	Small Exchange Replacement	2–4
2.4	Remote Access For Special Services	2–4
3	Operation Modes and Signalling Protocols	3–1
3.1	RIM Operational Modes	3–2
3.1.1	Non–Integrated Access Mode	3–2
3.1.2	Integrated Access Mode	3–3
3.1.3	Partially Integrated Mode	3–4
3.1.4	Concentration	3–5
3.2	Integrated Signalling Protocols	3–6
3.2.1	Alcatel 1000 System 12 Interfaces	3–6
3.2.2	Ericsson AXE Interface	3–7
3.2.3	Integrated Services Summary	3–8
4	System Configuration	4–1
4.1	Overview	4–2
4.2	Traditional RIM Architecture	4–3
4.2.1	Panel Overview	4–3
4.2.2	Panel Layouts	4–5
4.2.3	RIM Units	4–9
4.3	Compact RIM (C–RIM) Architecture	4–20
4.3.1	C–RIM Panel Overview	4–20

4.3.2	C–RIM Panel Layouts	4–22
4.3.3	C–RIM Units	4–27
4.4	RIM and C–RIM Releases – Feature Summary ...	4–30
4.4.1	RIM Release 1	4–30
4.4.2	RIM Release 2	4–30
4.4.3	RIM Release 3	4–31
4.4.4	RIM Release 3.1	4–32
4.4.5	RIM Release 4	4–33
4.4.6	RIM Release 5	4–33
4.4.7	RIM Release 6.1	4–34
4.4.8	C–RIM Release 7.1	4–35
4.4.9	C–RIM Release 8.0	4–36
4.4.10	C–RIM Release 8.2	4–37
5	Remote Unit Housings	5–1
5.1	Remote Housing Types	5–2
5.2	480 Line 1G Housing	5–3
5.2.1	Weight	5–3
5.2.2	Environmental Limits	5–3
5.2.3	Doors	5–4
5.2.4	Fixtures	5–4
5.2.5	Alarms	5–4
5.2.6	Compartments	5–5
5.2.7	The Climate Control System	5–7
5.3	240 Line 1G Remote Housing	5–10
5.4	180 Line Housing	5–11
5.4.1	Main Equipment Compartment	5–11
5.4.2	Power Supply Subsystem	5–12
5.4.3	Climate Control	5–12
5.4.4	Dimensions and Weight	5–12
5.4.5	Environmental Limits	5–12
5.4.6	Plinth and Batteries	5–12
5.5	480 Line 2G Housing	5–13
5.5.1	Main Equipment Compartment	5–13
5.5.2	Power Supply Subsystem	5–13
5.5.3	Climate Control	5–14
5.5.4	Dimensions and Weight	5–14
5.5.5	Environmental Limits	5–14
5.5.6	Plinth and Batteries	5–14
5.6	Underground CAN Equipment Housing	5–15
5.6.1	UCEH Inside Dimensions	5–16
5.7	RCM	5–17
6	Operations and Maintenance	6–1
6.1	General	6–2

6.1.1	OA&M Interfaces	6-3
6.2	COMNET-2 Network Management	6-4
6.2.1	COMNET-2 System Architecture	6-6
6.2.2	COMNET-2 Operations System (COS) ...	6-7
6.2.3	COMNET-2 Access Workstations (CAW) .	6-7
6.2.4	COMNET-2 NECTAS Workstations	6-7
6.2.5	RIMs and MDrs	6-7
6.2.6	Functions Summary	6-8
7	RIM Ordering	7-1
7.1	Ordering Process – Outline	7-2
7.2	RIMTOOL	7-3
7.2.1	Login	7-3
7.2.2	Architecture And Options	7-3
7.2.3	Select Panel Types	7-6
7.2.4	RIMTOOL Output	7-7
7.3	RIM and C-RIM Ordering Procedure	7-8
8	Installation Services.	8-1
8.1	RIM Extended Delivery Service	8-2
8.1.1	Ordering REDS	8-2
8.1.2	REDS Installation	8-2
8.2	MITS Data Transfer	8-4
	Glossary	GI-1
	Appendix A Abbreviations	A-1
	Appendix B RIM/System 12 Comparison	B-1
	Appendix C RIM Documents List	C-1
	Appendix D RIM Serial/Item List	D-1
	Index	In-1

Figures

Figure 1–1	RIM System Block Diagram	1–3
Figure 1–2	RIM Functional Block Diagram	1–6
Figure 1–3	C–RIM Functional Block Diagram	1–6
Figure 1–4	RIM OA&M Functions	1–7
Figure 2–1	Integrated and Non–integrated Pair Gain Application ..	2–3
Figure 4–1	Typical RIM EU Rack Layouts	4–5
Figure 4–2	Typical RIM RU Indoor Panel Layouts	4–7
Figure 4–3	480 Line 1G Remote Housing	4–8
Figure 4–4	Typical RIM 480 Line 1G Housing Layout	4–8
Figure 4–5	ISDN Arrangement	4–13
Figure 4–6	Typical C–RIM EU Rack Layouts	4–22
Figure 4–7	Typical C–RIM RU Indoor Panel Layouts	4–23
Figure 4–8	Typical C–RIM 480 Line 1G RU Housing Layout	4–24
Figure 4–9	C–RIM 180 Line RU Housing layout	4–25
Figure 4–10	C–RIM 480 Line 2G RU Housing layout	4–26
Figure 5–1	480 Line 1G Remote Housing	5–3
Figure 5–2	Power Compartment Layout	5–6
Figure 5–3	MEC cooling system air flow	5–8
Figure 5–4	Power compartment cooling system air flow	5–9
Figure 5–5	240 Line 1G Remote Housing	5–10
Figure 5–6	C–RIM 180 Line RU Housing and Plinth	5–11
Figure 5–7	C–RIM 480 Line 2G Housing	5–13
Figure 5–8	UCEH–Small – Cross–section	5–15
Figure 6–1	OA&M functions – Traditional RIM	6–2
Figure 6–2	OA&M functions – C–RIM	6–3
Figure 6–3	RIM & C–RIM OA&M functions (via COMNET–2)	6–5
Figure 6–4	COMNET–2 System Architecture	6–6
Figure 6–5	COMNET–2 Intercommunication	6–9
Figure 6–6	Alarm System	6–10
Figure 6–7	Alarm Agent	6–10
Figure 6–8	Service assignment and verification process	6–11
Figure 7–1	RIMTOOL – Architecture and Options Screen	7–3
Figure 7–2	RIMTOOL – Select Panels	7–6
Figure 7–3	Panel Description	7–6
Figure 7–4	RIMTOOL – Materials and Resource Modules Lists	7–7
Figure 7–5	Forecasting, RIMTOOL and Projects System	7–8
Figure 7–6	BISTEL and Purchase Order	7–9

Tables

Table 3–1	Integrated Services Summary	3–8
Table 4–1	Panel Types and Functions – RIM	4–4
Table 4–2	POTS RU Interface Specification	4–10
Table 4–3	POTS EU Interface Specification	4–11
Table 4–4	UNIV–RU Interface Specification	4–11
Table 4–5	UNIV–EU Interface Specification	4–11
Table 4–6	4/6 Wire Interface Specification	4–12
Table 4–7	P–Phone Wire Interface Specification	4–12
Table 4–8	64KB–E&M Interface Specification	4–12
Table 4–9	2B1Q Interface Specification	4–13
Table 4–10	4B3T Interface Specification	4–13
Table 4–11	Channel Card Function Summary	4–14
Table 4–12	8 Mbit/s Dual–Fibre Optomux Interface Specification	4–16
Table 4–13	8 Mbit/s LCFO I/F Specification	4–17
Table 4–14	34 Mbit/s LCFO I/F Specification	4–17
Table 4–15	34 Mbit/s Single fibre LCFO I/F Specification	4–18
Table 4–16	34 Mbit/s Electrical Interface Specification	4–18
Table 4–17	Panel Types and Functions – C–RIM	4–21
Table 4–18	Optical Interface – OMX 4x2	4–27
Table 4–19	Optical Interface – OMX 16x2M	4–28
Table 5–1	UCEH Inside Dimensions	5–16

